Electrolux Group

TECH TIP

CKTT2422

02.23.24

MW Error Codes

BRAND: Electrolux Frigidaire Ikea

MODEL: FPMO3077TF EMBD3010AS FGMO3067UF FGMO3067UD CPBM3077RF FGMO226NUD EI30BM60MS EI30BM6CPS FPBM3077RF FFMV1645TS FFMV1645TD FFMV1645TH FFMV1645TB FFMV1645TW LFMV1645TF FFMV1745TS FFMV1745TB FFMV1745TW FGMV176NTD FGMV176NTF FGMV176NTW FGMV176NTB FGMV17WNVF 004.621.66 FGMV17WNVD FGMV155CTF CFMV1645TS CFMV1645TB CFMV1645TW 304.692.94 CFMV1645TD CGMV176NTD CGMV176NTF CGMV176NTW CGMV176NTB 004.692.95 CGMV17WNVF CGMV17WNVD UMV1422US UMV1422UW FGBM19WNVF 704.621.63 FGBM19WNVD FGBM15WCVF FFMV1846VS FFMV1846VW FFMV1846VB 204.621.65 FFMV1846VD LFMV1846VF FPMO227NUF CGMO226NUF CPMO227NUF 504.692.93 EMOW1911AS FFMO1611LB FFMO1611LS FFMO1611LW FGMO226NUF 504.621.64

SERIAL: All

CONDITION: Unit is displaying an error code.

SOLUTION: Reference the chart below:

Code	Purpose of Detection	Error Condition	Timing
E-01	Temperature Sensor Open	Unplug the temperature sensor in any state.	All the time
E-02	Temperature Sensor Shorted	Short-circuit temperature sensor in any state.	All the time
E-04	Humidity Sensor Error	Start the humidity sensing menu without connecting the humidity sensor (Only Valid for Sensor Menu)	After humidity menu works 20sec.
E-11	The Control Button Circuit is Shorted	A fault code appears when touched.	All the time
E-17	Preheating Error	The warm-up time is less than the set temperature for 15 minutes. (Unit Returns to Standby Mode)	All the time

For Additional Questions Please Contact The Electrolux Technical Support Team: 1-888-842-3660

SOLUTION CONT:

Code	Purpose of Detection	Error Condition	Timing
F1	Temperature Sensor Open	Unplug the temperature sensor in any state.	All the time
F2	Temperature Sensor Shorted	Short-circuit temperature sensor in any state.	All the time
F4	Humidity Sensor Error	Start the humidity sensing menu without connecting the humidity sensor (Only Valid for Sensor Menu)	After humidity menu works 20sec.
UNPLUG	The Control Button Circuit is Shorted	A fault code appears when touched.	All the time

For Additional Questions Please Contact The Electrolux Technical Support Team: 1-888-842-3660